

CETA 101


Double temperature difference control

Connections




Control system CETA

Device connection



Control system CETA


Device connection



1/2/3
L1 (Switching output)


Control system CETA

Device connection



Control system CETA

Device connection




The following communication takes place via the A/B bus:

- Outdoor sensor value
- Burner blocking
- Start protection
- Buffer priority

**CETA-Bus A/B
for connection
with further CETA devices
(not CETA RC)**

Control system CETA


Device connection



**A room control / remote control
CETA-RC is connected to the RC
terminals.**


Control system CETA

Device connection



Regelsystem CETA

Geräteanschluss



Sie haben noch Fragen?

Unseren telefonischen Support erreichen Sie unter
der Tel. +49 2736 44305 901

