



Installations-Stick



(Abb. ähnlich / Fig. similar)

0450000521-1534

DE Installationsanleitung

Sicherheitshinweise

- Das Gerät ist nicht für Kinder geeignet und darf nicht als Spielzeug verwendet werden.
- Verpackungsmaterialien kindersicher lagern oder entsorgen.
- Das Gerät nicht zerlegen, es enthält keine vom Benutzer zu wartenden Teile.

Beschreibung

Der **heatapp! Installations-Stick** wird eingesetzt, um die Ersteinrichtung über ein Tablet oder Smartphone durchzuführen.

Über den **heatapp! Installations-Stick** wird eine WLAN-Verbindung zur **heatapp! base** oder **heatapp! gateway** hergestellt.

Eine ausführliche Beschreibung des **heatapp!** Systems finden Sie in der Bedienungsanleitung unter www.heatapp.de

heatapp! Installations-Stick anschließen

Stecken Sie den **heatapp! Installations-Stick** (1) in eine der USB-Buchsen an der Oberseite der **heatapp! base** oder an die USB-Buchse des **heatapp! gateway**.

Der angezeigte Netzwerkname wird von der **heatapp! base** bzw. dem **heatapp! gateway** erzeugt:

- heatapp! base [xxxxxx]
- heatapp! gateway [xxxxxx]

In den eckigen Klammern werden die letzten 6 Stellen der Mac-Adresse von **heatapp! base** bzw. **heatapp! gateway** (befindet sich auf dem Typenschild) angezeigt.


Inbetriebnahme

- Wählen Sie in Ihrem Tablet/Smartphone die WLAN-Einstellungen aus.
- Stellen Sie eine Verbindung mit dem Netzwerk der **heatapp! base** bzw. des **heatapp! gateway** her. Die Eingabe eines Netzwerkschlüssels ist nicht erforderlich.

Je nach Einstellungen des Tablets/Smartphones öffnet sich der Browser automatisch oder Sie öffnen den Standardbrowser Ihres Geräts und geben in die Adresszeile 10.0.0.1 ein.

Folgen Sie den Anweisungen des Einrichtungsassistenten (Einzelheiten in der Installationsanleitung **heatapp! base** und **heatapp! gateway**).

- Entfernen Sie nach Abschluss der Installation den **heatapp! Installations-Stick**.



Installations-Stick



(Abb. ähnlich / Fig. similar)

0450000521-1534

DE Installationsanleitung

Sicherheitshinweise

- Das Gerät ist nicht für Kinder geeignet und darf nicht als Spielzeug verwendet werden.
- Verpackungsmaterialien kindersicher lagern oder entsorgen.
- Das Gerät nicht zerlegen, es enthält keine vom Benutzer zu wartenden Teile.

Beschreibung

Der **heatapp! Installations-Stick** wird eingesetzt, um die Ersteinrichtung über ein Tablet oder Smartphone durchzuführen.

Über den **heatapp! Installations-Stick** wird eine WLAN-Verbindung zur **heatapp! base** oder **heatapp! gateway** hergestellt.

Eine ausführliche Beschreibung des **heatapp!** Systems finden Sie in der Bedienungsanleitung unter www.heatapp.de

heatapp! Installations-Stick anschließen

Stecken Sie den **heatapp! Installations-Stick** (1) in eine der USB-Buchsen an der Oberseite der **heatapp! base** oder an die USB-Buchse des **heatapp! gateway**.

Der angezeigte Netzwerkname wird von der **heatapp! base** bzw. dem **heatapp! gateway** erzeugt:

- heatapp! base [xxxxxx]
- heatapp! gateway [xxxxxx]

In den eckigen Klammern werden die letzten 6 Stellen der Mac-Adresse von **heatapp! base** bzw. **heatapp! gateway** (befindet sich auf dem Typenschild) angezeigt.


Inbetriebnahme

- Wählen Sie in Ihrem Tablet/Smartphone die WLAN-Einstellungen aus.
- Stellen Sie eine Verbindung mit dem Netzwerk der **heatapp! base** bzw. des **heatapp! gateway** her. Die Eingabe eines Netzwerkschlüssels ist nicht erforderlich.

Je nach Einstellungen des Tablets/Smartphones öffnet sich der Browser automatisch oder Sie öffnen den Standardbrowser Ihres Geräts und geben in die Adresszeile 10.0.0.1 ein.

Folgen Sie den Anweisungen des Einrichtungsassistenten (Einzelheiten in der Installationsanleitung **heatapp! base** und **heatapp! gateway**).

- Entfernen Sie nach Abschluss der Installation den **heatapp! Installations-Stick**.



Technische Daten

WLAN	802.11b/g/n
Chipsatz	Abgestimmt auf heatapp!
Umgebungsbedingungen	
• Lagertemperatur	-25 ... +60 °C
• Betriebstemperatur	-10 ... +50 °C
Gewicht	ca. 20 g

EN Installation instructions

Safety instructions

- The device is not suitable for children and must not be used as a toy.
- Store packaging material safely away from children or dispose of it.
- Do not dismantle the device; it does not contain any user-serviceable parts.

Description

The **heatapp! Installation Stick** is used for the installation setup on a tablet or smartphone.

The **heatapp! Installation Stick** connects **heatapp! base** or **heatapp! gateway** via WLAN.

You can find a detailed description of the **heatapp! system** in the manual under www.heatapp.de

Connect the heatapp! Installation-Stick

Plug the **heatapp! Installation Stick** (1) into one of the USB ports at the top of the **heatapp! base** or to the USB port of the **heatapp! gateway**.

The displayed network name is generated from the **heatapp! base** or the **heatapp! gateway**:

- heatapp! base [xxxxxx]
- heatapp! gateway [xxxxxx]

The last 6 digits of the Mac address of the **heatapp! base** or the **heatapp! gateway** (located on the nameplate) are shown in the brackets.

Initial operation

Choose the wireless settings on your tablet / smartphone.

- Connect to the network of the **heatapp! base** or the **heatapp! gateway**. A network key is not necessary .
- Depending on the settings of your tablet / smartphone, the browser will open automatically, or you open the default browser on your device and enter 10.0.0.1 in the address line.

Follow the instructions of the setup wizard (detailed description of the **heatapp! system** in the installation manual for **heatapp! base** and **heatapp! gateway**).

- Remove the Installation-Stick after the setup-wizard is finished.

Technical data

Wi-Fi	802.11b/g/n
Chip set	Matched to the heatapp!
Ambient conditions	
• Storage temperature	-25 ... +60 °C
• Operating temperature	-10 ... +50 °C
Weight	Approx. 20 g



EbV
Elektronikbau und Vertriebs-GmbH
Heisterner Weg 8-12
D-57299 Burbach

www.heatapp.de
info@heatapp.de



The device must be disposed of as electronic waste.

Technische Daten

WLAN	802.11b/g/n
Chipsatz	Abgestimmt auf heatapp!
Umgebungsbedingungen	
• Lagertemperatur	-25 ... +60 °C
• Betriebstemperatur	-10 ... +50 °C
Gewicht	ca. 20 g

EN Installation instructions

Safety instructions

- The device is not suitable for children and must not be used as a toy.
- Store packaging material safely away from children or dispose of it.
- Do not dismantle the device; it does not contain any user-serviceable parts.

Description

The **heatapp! Installation Stick** is used for the installation setup on a tablet or smartphone.

The **heatapp! Installation Stick** connects **heatapp! base** or **heatapp! gateway** via WLAN.

You can find a detailed description of the **heatapp! system** in the manual under www.heatapp.de

Connect the heatapp! Installation-Stick

Plug the **heatapp! Installation Stick** (1) into one of the USB ports at the top of the **heatapp! base** or to the USB port of the **heatapp! gateway**.

The displayed network name is generated from the **heatapp! base** or the **heatapp! gateway**:

- heatapp! base [xxxxxx]
- heatapp! gateway [xxxxxx]

The last 6 digits of the Mac address of the **heatapp! base** or the **heatapp! gateway** (located on the nameplate) are shown in the brackets.

Initial operation

Choose the wireless settings on your tablet / smartphone.

- Connect to the network of the **heatapp! base** or the **heatapp! gateway**. A network key is not necessary .
- Depending on the settings of your tablet / smartphone, the browser will open automatically, or you open the default browser on your device and enter 10.0.0.1 in the address line.

Follow the instructions of the setup wizard (detailed description of the **heatapp! system** in the installation manual for **heatapp! base** and **heatapp! gateway**).

- Remove the Installation-Stick after the setup-wizard is finished.

Technical data

Wi-Fi	802.11b/g/n
Chip set	Matched to the heatapp!
Ambient conditions	
• Storage temperature	-25 ... +60 °C
• Operating temperature	-10 ... +50 °C
Weight	Approx. 20 g



EbV
Elektronikbau und Vertriebs-GmbH
Heisterner Weg 8-12
D-57299 Burbach

www.heatapp.de
info@heatapp.de



The device must be disposed of as electronic waste.