

# CETA 104


## Heating circuit control

Connection




# Control system CETA

## Device connection



# Control system CETA


## Device connection



**1/2/3**  
**L1 (Switching output)**


# Control system CETA

## Device connection



# Control system CETA

## Device connection




The following communication takes place via the A/B bus:

- Outdoor sensor value
- Burner blocking
- Start protection
- Buffer priority

**CETA-Bus A/B  
for connection  
with further CETA devices  
(not CETA RC)**

# Control system CETA


## Device connection



**OpenTherm  
connection for communication  
between an OT burner control  
and a CETA 104.**

# Control system CETA



## Device connection



**A room control / remote control  
CETA-RC is connected to the RC  
terminals.**

# Control system CETA

## Device connection




**Sensor connection F1/F2/F3/F4**



# Control system CETA

## Device connection



# Do you have any questions?

You can reach our support by e-mail to  
[support@ebv-gmbh.de](mailto:support@ebv-gmbh.de)

